

SAMSUNG

Washing Machine Owner's Instructions

J147(W/V/C/S/R)

J127(W/V/C/S/R)

B147(W/V/C/S/R)

B127(W/V/C/S/R)



Register your product at
www.samsung.com/global/register
Code No.: DC68-02410N_EN

the 1990s, the number of people in the UK who are employed in the public sector has increased by 1.5 million, from 2.5 million in 1980 to 4 million in 1995. The public sector has become a major employer in the UK, and its growth has been a major factor in the overall growth of the economy.

The public sector has also become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy.

The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy.

The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy.

The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy.

The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy.

The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a major factor in the overall growth of the economy.

Features

1. **Silver Wash (Ag⁺)**

Samsung's silver Nano feature uses silver nano particles to sanitize and disinfect your laundry and your machine's drum. Delicates as well as smelly socks will get odor-free from human sweat at temperature as low as 30°C. That saves energy and protects color and shape of your clothes.

2. **Child Lock**

The Child Lock function keeps curious little hands out of the washer. This safety feature ensures, that children do not toy with the operation of the washer. It also alerts you when it is activated.

3. **Delay Start**

This function enables users to delay the washing machine's starting time for up to 24 hours.

4. **Calm Wash**

We have a wash cycle that is so quiet you can do laundry while you sleep. The spin cycle is whisper quiet as it drains away water.

5. **Less Ironing**

Less ironing is needed as Samsung's Carefreewash safely cleans your soft, delicate cloths and easy-care fabrics. Developed by Samsung's globally recognized digital process technology, the Less Iron function is a specialized laundry program that will help to reduce wrinkles on your delicate garments, freeing up the time you would have spent on ironing.

6. **Delicates & Wool Program**

Special care can be determined by the appropriate temperature, the gentle wash action and the appropriate amount of water.

7. **Air Wash**

The Air Wash system deodorizes unpleasant smells and sterilizes 'bacteria' and mites in the laundry that cannot be eliminated through a conventional washing system, a benefit of its unique air-washing mechanism.

- Air-washable : Woolen coats, cotton/down jumpers, sweaters, suits, pillows, cushions, needlework dolls
- Not applicable : leather, silk, velvet, electric blankets, other dirty laundry

Safety Precautions

Congratulations on your purchase of this Samsung washing machine. These Owner's Instructions contain valuable information on the installation, use, and care of this appliance. Please take the time to read these instructions so that you can take full advantage of the washing machine's features and enjoy this appliance for many years to come.

Before using the appliance

- Packing materials can be dangerous to children; keep all packing material (plastic bags, polystyrene, etc.) well out of the reach of children.
- The appliance is designed for home use only.
- Make sure that water and electrical connections are made by qualified technicians, observing the manufacturer's instructions (see "Installing the Washing Machine") and local safety regulations.
- All packaging and shipping bolts must be removed before the appliance is used. Serious damage may occur if they are not removed. See "Removing the shipping bolts".
- Before washing clothes for the first time, you must run a complete cycle without clothes. See "Washing for the first time".

Safety instructions

- Before cleaning or carrying out maintenance, unplug the appliance from the electrical outlet or set the Ⓢ (On/Off) button to Off.
- Make sure that the pockets of all clothing to be washed are empty. Hard, sharp objects, such as coins, safety pins, nails, screws, or stones can cause extensive damage to the appliance.
- Always unplug the appliance and turn off the water after use.
- Before you open the door of the appliance, check that the water has drained. Do not open the door if you can still see water.
- Pets and small children may climb into the appliance. Check the appliance before each use.
- The glass door becomes very hot during the washing cycle. Keep children away from the appliance while it is in use.
- Do not attempt to repair the appliance yourself. Repairs made by inexperienced or unqualified persons may cause injury and/or make more serious repairs to the appliance necessary.
- If the plug (power supply cord) is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This appliance should only be serviced by an authorized service center, and only genuine spare parts should be used.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely. Young children should be supervised to ensure that they do not play with the appliance.
- If this appliance is supplied from a cord extension set or an electrical portable outlet device, the cord extension set or electrical portable outlet device must be positioned so that it is not subject to splashing or ingress of moisture. Additionally, the cord extension set or electrical portable outlet device must be of a current rating suitable for the appliance.
- This appliance has to be connected to the plug endurable to proper power consumption.
- This appliance has to be positioned so that the plug is accessible after installation.
- Do not use processed water containing oil, cream or lotion, which is usually found in skin-care shops or massage clinics.
 - Otherwise this will cause the packing to be deformed, which causes a malfunction or water leak.
- A stainless washing tube does not usually rust. However if some metal such as a hair pin is left in the tube for an extended time, the tube could rust.
 - Do not leave water or bleach containing chlorine in the tube for an extended period of time.
 - Do not regularly use or leave water containing iron in the tube for an extended period of time. If rust starts appearing on the surface of the tube, apply a cleansing agent (neutral) to the surface and use a sponge or soft cloth to clean it. (Under no circumstances use a metal brush)
- For washing machines with ventilation openings in the base, that a carpet must not obstruct the openings.
- Use the new hose-sets and old hose-sets should not be reused.

Table of Contents


Safety Precautions	inside cover
Installing the Washing Machine.	A-1
Unpacking the washing machine	A-1
Overview of the washing machine	A-1
Selecting a location.	A-2
Adjusting the leveling feet	A-2
Removing the shipping bolts	A-2
Connecting the water supply hose	A-3
Positioning the drain hose	A-4
Washing a Load of Laundry	B-1
Overview of the control panel	B-1
Washing clothes using Fuzzy Logic	B-3
Washing clothes manually	B-4
Using delay start.	B-4
Washing for the first time.	B-5
Putting detergent in the washing machine	B-5
Washing tips and hints	B-6
Maintaining the Washing Machine	C-1
Draining the washing machine in an emergency	C-1
Repairing a frozen washing machine.	C-1
Cleaning the exterior	C-1
Cleaning the detergent drawer and recess	C-2
Cleaning the debris filter	C-2
Cleaning the water hose mesh filter	C-3
Troubleshooting	D-1
Problems and solutions	D-1
Understanding error messages.	D-1
Programme Chart	E-1
Appendix	F-1
Fabric care chart.	F-1
Electrical warnings	F-1
Protecting the environment.	F-2
Declaration of conformity	F-2
Specification	F-2

Installing the Washing Machine

Unpacking the washing machine

Unpack your washing machine and inspect it for shipping damage. Also make sure that you have received all of the items shown below. If the washing machine was damaged during shipping or you do not have all of the items, contact your Samsung dealer immediately.

Overview of the washing machine



Installing the Washing Machine

Selecting a location

Before you install the washing machine, select a location with the following characteristics:

- A hard, level surface (if the surface is uneven, see "Adjusting the leveling feet," below)
- Away from direct sunlight.
- Adequate ventilation
- Room temperature that will not fall below 0 °C
- Away from sources of heat such as coal or gas

Make sure that the washing machine does not stand on its power cord.

Ventilation openings must not be obstructed by carpeting when the washing machine is installed on a carpeted floor.


Adjusting the leveling feet

If the floor is uneven, adjust the feet (do not insert pieces of wood or any other objects under the feet):

1. Loosen the leg bolt by turning it with your hand until it is at the desired height.
2. Tighten the locking nut by turning it with the supplied wrench.

If the washer is placed on an uneven or weak surface, noise or vibration occurs.


(Only 1 degree angle is allowed.)



Removing the shipping bolts

Before using the washing machine, you must remove the five shipping bolts from the back of the unit. To remove the bolts:

1. Loosen all bolts with the supplied wrench before removing them.
2. Take each bolt head and pull it through the wide part of the hole. Repeat for each bolt.
3. Fill the holes with the supplied plastic covers.
4. Keep the shipping bolts for future use.




Installing the Washing Machine

Connecting the water supply hose

The water supply hose must be connected to the washing machine at one end and to the water faucet at the other. Do not stretch the water supply hose. If the hose is too short replace the hose with a longer, high pressure hose.

To connect the water supply hose:

1. Take the L-shaped arm fitting for the cold water supply hose and connect to the cold water supply intake on the back of the machine. Tighten by hand.
2. Connect the other end of the cold water supply hose to your sink's cold water faucet and tighten it by hand. If necessary, you can reposition the water supply hose at the washing machine end by loosening the fitting, rotating the hose, and retightening the fitting.





Option:

1. Take the red L-shaped arm fitting for the hot water supply hose and connect to the red hot water supply intake on the back of the machine. Tighten by hand.
2. Connect the other end of the hot water supply hose to your sink's hot water faucet and tighten it by hand.
3. Use a Y-piece if you only want to use cold water.

Installing the Washing Machine

Connecting the water supply hose (Option)

- | | |
|--|---|
| <p>1. Remove the adaptor from the water supply hose.</p>  | <p>4. Connect the water supply hose to the adaptor. Pull down part (c) of the water supply hose. When you release part (c) the hose automatically connects to the adaptor making a 'click' sound.</p>  |
| <p>2. First, using a '+' type screw driver, loosen the four screws on the adaptor. Next, take the adaptor and turn part(b) following the arrow until there is a 5mm gap.</p>  | <p>5. Connect the other end of the water supply hose to the inlet water valve at the rear of the washer. Screw the hose clockwise all the way in.</p>  |
| <p>3. Connect adaptor to the water tap by tightening the screws firmly. Then, turn part (b) following the arrow and put(a) and (b) together.</p>  | |


NOTICE After completing connection, if water leaks from the hose, then repeat the same steps. Use the most conventional type of faucet for water supply. In case the faucet is square or too big, remove the spacing ring before inserting the faucet into the adaptor.

Positioning the drain hose

The end of the drain hose may be positioned in three ways:

Over the edge of a wash basin.

The drain hose must be placed at a height of between 60 and 90 cm. To keep the drain hose spout bent, use the supplied plastic hose guide. Secure the guide to the wall with a hook or to the faucet with a piece of string to prevent the drain hose from moving.



In a sink drain pipe branch


The drain pipe branch must be above the sink siphon so that the end of the hose is at least 60 cm above the ground.

In a drain pipe

Samsung recommends that you use a 65 cm high vertical pipe; it must be no shorter than 60 cm and no longer than 90 cm.

Washing a Load of Laundry

Overview of the control panel



1. Digital graphic display

Displays the remaining wash cycle time, all of washing information and error messages.

2. Air Wash selection button

Press the button repeatedly to cycle through the Deodorization and Sterilization functions.

When the Air Wash function is selected, other cycles can no longer be used.

Deodorization : Removes bad smells from the laundry

Sterilization : Eliminates bacteria and mites from the laundry

3. Silver Nano selection button (Ag⁺)

Silver Nano water is supplied in washing as well as the last rinse, featuring sterilization and antibacterial coating. (You can select 'Sterilization' or 'Protection', 'Sterilization' + 'Protection'.)

4. Pre-wash+ selection button

Press the button to select pre-wash. Pre-wash is available only with Cotton, Coloureds, Synthetics, Heavy Soil.

5. Drying Time selection button

Press the button repeatedly to cycle through the available dry selections.

(120min. → 90min. → 60min. → 30min.)

6. Intensive selection button

When selected, the washing power increases. This function can be selected for the Cotton, Coloreds, Synthetics, Jeans, Heavy Soil, Mixed Load, and Calm Wash courses. Pressing this button toggles between On and Off.

7. Temperature selection button

Press the button repeatedly to cycle through the available water temperature options.

(cold(0°C), 30°C, 40°C, 60°C and 95°C)

The default temperature varies depending on the cycle. You can also choose a particular laundry temperature from the preset temperature options.

8. Rinse selection button

Press the rinse button to add rinse cycles. Maximum number of rinse cycles is five.


9. Spin selection button

Press the button repeatedly to cycle through the available spin speed options.

J147/B147	Rinse hold, No spin(0), 400, 800, 1200, 1400 rpm
J127/B127	Rinse hold, No spin(0), 400, 800, 1200 rpm

0 : no spin Non display : Rinse hold

Washing a Load of Laundry



10. Delay Start selection button

Press the button repeatedly to cycle through the available delayed start options (from 3 hour to 19 hours in one hour increments).
Displayed hours means the time of finished washing-cycle.

11. Less Ironing selection button

Less Ironing will reduce wrinkles and ironing time. (available course: Cotton, Coloureds, Synthetics, Jean, Quick, Heavy Soil, Mixed Load, Rinse + Spin, Spin)

12. Child Lock selection button

This is a button for preventing children from manipulating the washing machine.
On/Off - To set the program on: Press the Start/Pause button to turn on the washing machine. Press and hold down the [Intensive] + [Temp] button for 2-3 seconds. It can only be activated when the machine is turned on. Once you set the Child Lock on while in washing, no button is activated until you set it off. Even the POWER button will not be activated. The Child Lock lamp lights on. To set the program off: Press and hold down the [Intensive] + [Temp] button again for 2-3 seconds, then the lamp lights off and is set off.

NOTE: Check out the Child Lock button first when no button is activated while the washing machine is working.

13. Fuzzy Control dial

Turn the dial to select one of the 12 available wash programs

Cotton, Coloureds, Synthetics, Delicate Fabrics, Hand Wash For Wool, Jeans, Quick, Drying, Heavy Soil, Mixed Load, Calm Wash, Drain, Spin, Rinse+Spin

14. Start/Pause selection button

Press the Start/Pause button to pause or restart a cycle. If you want to change the washing cycle while a cycle is running, press this button to pause the currently running cycle, and press it again to restart the washing machine after choosing a different cycle.

15. ⏻ (On/Off) selection button

Press once to turn the washing machine on, press again to turn the washing machine off. If the washing machine power is left on for longer than 10 minutes without any buttons being touched, the power automatically turns off.

Washing a Load of Laundry


Washing clothes using Fuzzy Logic

Your new washing machine makes washing clothes easy, using Samsung's "Fuzzy Logic" automatic control system. When you select a wash programme, the machine will set the correct temperature, washing time, and washing speed.

To wash clothes using the Fuzzy Logic programs:

1. Turn on your sink's water faucet.
2. Press the ☺ (On/Off) button.
3. Open the door.
4. Load the articles one at a time loosely into the drum, without overfilling.
5. Close the door.
6. Add the detergent, softener, and prewash detergent (if necessary) into the appropriate compartment.
7. Turn the Fuzzy Control dial to select the appropriate program for the type of clothes Cotton, Coloureds, Synthetics, Delicate Fabrics, Hand Wash For Wool, Jeans, Quick, Drying, Heavy Soil, Mixed Load, Calm Wash, Drain, Spin, Rinse+Spin.

You will see the indicators light up on the control panel.



8. At this time, you can control the wash temperature, rinsing times, spin speed, delay time by pressing the appropriate option button.
9. Press the Start/Pause button on the Fuzzy Control dial and the wash cycle will begin. The process indicator will light up and the remaining time for the cycle will appear in the display.

Pause Option (Stop & Adding laundry Function)

Within 5 minutes from start, it is possible to put in the laundry or take out.

If push Start/Pause button, the door is unlocked immediately.

In case of too hot or too much water in washer, the door can not be opened.

After closed the door, one more push Start/Pause button to make washing process going on continuously.

When the cycle is finished:

After the total cycle has finished, the power will turn off automatically.

1. Open the door.
2. Remove laundry.

Washing a Load of Laundry

Washing clothes manually

You can wash clothes manually without using the Fuzzy Logic feature.

To do so:

1. Turn the water supply on.
2. Press the  (On/Off) button on the washing machine.
3. Open the door.
4. Load the articles one at a time loosely into the drum, without overfilling.
5. Close the door.
6. Put the detergent and, if necessary, softener or prewash detergent, in the appropriate compartments.
7. Press the Temperature button to select the temperature.
(cold(0°C), 30°C, 40°C, 60°C and 95°C)
8. Press to rinse button to select the required number of rinse cycles.
Maximum number of rinse cycles is five.
The washing duration will be prolonged accordingly.
9. Press the Spin button to select the spin speed. [0, 400, 800, 1200 or 1400 revolutions per minute(rpm)]
Notice: The rinse hold program allows you to take clothes that are dripping wet out of the washing machine.
0 : No spin , Non display : Rinse hold
10. Press the button repeatedly to cycle through the available delayed start options (from 3 hour to 19 hours in one hour increments). Displayed hours means the time of finished washing-cycle.
11. Press the Start/Pause button and the machine will begin the cycle.

Using delay start

You can set the washing machine to finish your wash automatically at a later time, choosing from 3 to 19 hour delay (in 1 hour increments). Displayed hours means the time of finished washing-cycle.

To do this:

1. Manually or automatically set your washing machine for the type of clothes you are washing.
2. Press the Delay Start button repeatedly until the delay time is set.
3. Press the Start/Pause button. The Delay Start indicator will light, and the clock will begin counting down until it reaches your finish time.
4. To cancel Delay Start, press the  (On/Off) button, then turn the washing machine on again.


Washing a Load of Laundry

Washing for the first time

Before washing clothes for the first time, you must run a complete cycle without clothes.

To do this:

1. Press the  (On/Off) button.
 2. Pour a little detergent into compartment (II) in the detergent drawer.
 3. Turn on the water supply to the washing machine.
 4. Press the Temperature button repeatedly until 40 °C is displayed.
 5. Press the Start/Pause button.
- This will remove any water from the manufacturer's test run remaining in the machine.



Dispenser ①: Detergent for prewash or starch.

Dispenser ②: Detergent for main wash, water softener, pre-soaking agent, bleach and stain removal product.


Dispenser : Additives, e.g. fabric softener or former (fill no higher than lower edge of insert "A")

Putting detergent in the washing machine

1. Pull out the detergent drawer.
2. Add laundry detergent into compartment (II).
3. Add softener into compartment () (if you desire).
4. Add prewash detergent into compartment (I) (if you desire).

Caution :

Concentrated or thick fabric softener and conditioner must be diluted with a little water before being poured into the dispenser (prevents the overflow from becoming blocked).



Washing a Load of Laundry

Washing tips and hints

Sorting your laundry: Sort your laundry according to the following characteristics:

- **Type of fabric care label symbol:** Sort laundry into cottons, mixed fibres, synthetics, silks, wools and rayon.
- **Colour:** Divide whites and colours. Wash new, coloured items separately.
- **Size:** Placing items of different sizes in the same load will improve the washing action.
- **Sensitivity:** Wash delicate items separately, using the Delicate wash programme for pure new wool, curtains and silk articles. Check the labels on the items you are washing or refer to the fabric care chart in the appendix.

Emptying pockets: Coins, safety pins and similar items can damage linen, the washing machine drum, and the water tank.

Securing fasteners: Close zippers and fasten buttons or hooks; loose belts or ribbons should be tied together.

Prewashing cotton: Your new washing machine, combined with modern detergents, will give perfect washing results, thus saving energy, time, water and detergent. However, if your cotton is particularly dirty, use a prewash with a protein-based detergent.

Determining load capacity: Do not overload the washing machine or your laundry may not wash properly. Use the chart below to determine the load capacity for the type of laundry you are washing.

Fabric Type	Load Capacity	
	J147/J127	B147/B127
Cotton/Coloureds	7.0 kg	6.0 kg
Synthetics	3.0 kg	3.0 kg
Delicates	2.5 kg	2.5 kg
Hand Wash For Wool	2.0 kg	2.0 kg

Detergent tips: The type of detergent you should use is based on the type of fabric (cotton, synthetics, delicates items, Hand Wash For Wool), colour, wash temperature, degree and type of soiling.

Always use “low suds” laundry soap, which is designed for automatic washing machines.


Follow the detergent manufacturer’s recommendations based upon the weight of the laundry, the degree of soiling, and the hardness of the water in your area. If you do not know how hard your water is, ask your water authority.

Notice: Keep detergents and additives in a safe, dry place out of the reach of children.


Maintaining the Washing Machine

Draining the washing machine in an emergency

1. Unplug the washing machine from the power supply.
2. Open the filter-cover by using a coin or a key.



3. Unscrew the emergency drain cap by turning left. Grip the cap on the end of the emergency drain tube and slowly pull it out about 15 cm.



4. Allow all the water to flow into a bowl.
5. Reinsert the drain tube and screw the cap back on.
6. Replace the filter-cover.

Repairing a frozen washing machine

If the temperature drops below freezing and your washing machine is frozen:

1. Unplug the washing machine.
2. Pour warm water on the source faucet to loosen the water supply hose.
3. Remove the water supply hose and soak it in warm water.
4. Pour warm water into the washing machine drum and let it sit for 10 minutes.
5. Reconnect the water supply hose to the water faucet and check if the water supply and drain operations are normal.




Cleaning the exterior

1. Wipe the washing machine surfaces, including the control panel, with a soft cloth and non-abrasive household detergents.
2. Use a soft cloth to dry the surfaces.
3. Do not pour water on the washing machine.

Maintaining the Washing Machine

Cleaning the detergent drawer and recess

1. Press the release lever on the inside of the detergent drawer and pull it out.
2. Remove the cap from compartment (⊗).
3. Wash all of the parts under running water.
4. Clean the drawer recess with an old toothbrush.
5. Reinsert the cap (Pushing it firmly into place) and replace the liquid detergent divider into the drawer.
6. Push the drawer back into place.
7. Run a rinse programme without any laundry in the drum.




Cleaning the debris filter

Clean the debris filter 5 or 6 times a year, or when you see the following error message on the display:

5E

1. Open the filter-cover, See "Draining the washing machine in an emergency" on page C-1.
2. Unscrew emergency drain cap by turning left and drain off all the water. See "Draining the washing machine in an emergency" on page C-1.
3. Unscrew the filter cap and take it out.
4. Wash any dirt or other material from the filter. Make sure the drain pump propeller behind the filter



- is not blocked. Replace the filter cap.
5. Replace the filter-cover.

Maintaining the Washing Machine



Cleaning the water hose mesh filter

You should clean the water hose mesh filter at least one time per year, or when you see the following error message on the display:

4E

To do this:

1. Turn off the water source to the washing machine.
2. Unscrew the hose from the back of the washing machine.
3. With a pair of pliers, gently pull out the mesh filter from the end of the hose and rinse it under water until clean. Also clean the inside and outside of the threaded connector.



4. Push the filter back into place.
5. Screw the hose back onto the washing machine.
6. Turn on the faucet and make sure the connections are watertight.

Troubleshooting

Problems and solutions

The washing machine will not start

- Make sure the door is firmly closed.
- Make sure the washing machine is plugged in.
- Make sure the water source faucet is turned on.
- Make sure to press the Start/Pause button.

No water or insufficient water supply

- Make sure the water source faucet is turned on.
- Make sure the water source hose is not frozen.
- Make sure the water intake hose is not bent.
- Make sure the filter on the water intake hose is not clogged.

Detergent remains in the detergent drawer after the wash programme is complete

- Make sure the washing machine is running with sufficient water pressure.
- Put the detergents in the inner parts of the detergent drawer (away from the outside edges).

Washing machine vibrates or is too noisy

- Make sure the washing machine is set on a level surface. If the surface is not level, adjust the washing machine feet to level the appliance.
- Make sure that the shipping bolts are removed.
- Make sure the washing machine is not touching any other object.
- Make sure the laundry load is balanced.

The washing machine does not drain and/or spin

- Make sure the drain hose is not squashed or bent.
- Make sure the water hose mesh filter is not clogged.

The Door does not open

1. Disconnect the power plug from the power supply.
2. Remove the water from the washing machine.
3. Open the filter cover using a coin.
4. Locate the orange plastic tab and pull forward to open the door.

Understanding error messages

Error displayed	Solution
dE2	• Close the door.
4E	• Make sure the source water faucet is turned on. • Check the water pressure.
5E	• Clean the debris filter. • Make sure the drainage hose is installed correctly.
UE	• Laundry load is unbalanced; loosen any tangled laundry. If only one item of clothing needs washing, such as a bathrobe or jeans, the final spin result might be unsatisfactory and an "UE" error message will be shown in the display window.
cE / 3E	• Call after-sales service.
HOT	• Displayed when the door does not open for high temperature.

Before contacting After-Sales service:

1. Try to remedy the problem (See "Troubleshooting" on this page).
2. Restart the programme to see if the fault is repeated.
3. If the malfunction persists, call after-sales service and describe the problem.

Programme Chart

(* user option)

Programme	Max Load(kg)		Detergent and Additives			Temp. (°C)	Spin Speed(Max) rpm		Delay start	Cycle Time (min)
	J147/ J127	B147/ B127	prewash	wash	softener		J147/ B147	J127/ B127		
Cotton	7.0	6.0	*	yes	*	95	1400	1200	*	89
Coloureds	7.0	6.0	*	yes	*	60	1400	1200	*	97
Synthetics	3.0	3.0	*	yes	*	60	1200	1200	*	69
Delicates Fabrics	2.5	2.5	-	yes	*	40	800	800	*	52
Handwash for Wool	2.0	2.0	-	yes	*	40	800	800	*	39
Jeans	2.0	2.0	-	yes	*	40	800	800	*	59
Quick	3.0	3.0	-	yes	*	60	1400	1200	*	27

Programme	Type of WASH
Cotton	Averagely or lightly soiled cottons, bed linen, table linen, underwear, towels, shirts, etc.
Coloureds	Averagely or lightly soiled cottons, bed linen, table linen, underwear, towels, shirts, etc.
Synthetics	Averagely or lightly soiled blouses, shirts, etc. Made of polyester (Diolen, Trevira), polyamide (perlon, Nylon) or other similar blends.
Delicates Fabrics	Delicate curtains, dresses, skirts, shirts and blouses.
Handwash for Wool	Only machine washable woolens with pure new wool label.
Quick	Lightly soiled cottons or linen blouses, shirts, dark coloured terry cloth, coloured linen articles, jeans, etc.

1. The programme duration data has been measured under the conditions specified in Standard IEC 456.
2. Consumption in individual homes may differ from the values given in the table due to variations in the pressure and temperature of the water supply, the load and the type of laundry.

Programme Chart

(* user option))

Programme	Max Load(kg)		Detergent and Additives			Temp. (°C)	Spin Speed(Max) rpm		Delay start	Cycle Time (min)
	J147/ J127	B147/ B127	prewash	wash	softener	max	J147/ B147	J127/ B127		
Drying	3.5	3.0	-	-	-	-	-	-	*	120
Heavy Soil	7.0	6.0	*	yes	*	60	1400	1200	*	108
Mixed Load	2.5	2.5	-	yes	*	60	800	800	*	75
Calm Wash	3.0	3.0	-	yes	*	40	-	-	*	95

Programme	Type of WASH
Heavy Soil	Stained or heavily soiled cottons, bed linen, table linen, underwear, towels, shirts, jeans, etc.
Mixed Load	A mix of lightly soiled cottons and synthetic fabrics.
Calm Wash	Extremely low noise level during the entire cycle and finish rinse hold. Cottons, bed linen, table linen, underwear, towels, shirts.

Appendix

Fabric care chart

	Resistant material		Can be ironed at 100 °C max
	Delicate fabric		Do not iron
			Can be dry cleaned using any solvent
			Dry clean with perchloride, lighter fuel, pure alcohol or R113 only
			Dry clean with aviation fuel, pure alcohol or R113 only
			Do not dry clean
	Item may be hand washed		Dry flat
	Dry clean only		Can be hung to dry
	Can be bleached in cold water		Dry on clothes hanger
	Do not bleach		Tumble dry, normal heat
	Can be ironed at 200 °C max		Tumble dry, reduced heat
	Can be ironed at 150 °C max		Do not tumble dry

Electrical warnings

To reduce the risk of fire, electrical shock, and other injuries, keep these safety precautions in mind:

- Operate the appliance only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your appliance dealer or local power company.
- Use only a grounded or polarized outlet. For your safety, this appliance is equipped with a polarized alternating current line plug having one blade wider than the other. This plug will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still doesn't fit, contact your electrician to replace your outlet.
- Protect the power cord. Power supply cords should be routed so that they are unlikely to be walked on or pinched by items placed on or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the unit.
- Do not overload the wall outlet or extension cords. Overloading can result in fire or electric shock.

Appendix

Protecting the environment

- This appliance is manufactured from recyclable materials. If you decide to dispose of this appliance, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance.
- Do not exceed the detergent quantities recommended in the detergent manufacturers' instructions.
- Use stain removal products and bleaches before the wash cycle only when strictly necessary.
- Save water and electricity by only washing full loads (the exact amount depends upon the programme used).

Declaration of conformity

This appliance complies with European safety standards, EC directive 93/68 and EN Standard 60335.

Specification

TYPE		FRONT LOADING WASHER			
DIMENSION		J147/J127		B147/B127	
		W598mm X D600mm X H844mm		W598mm X D550mm X H844mm	
WATER PRESSUERE		50 kPa ~ 800 kPa			
WATER VOLUME		60 ℓ		54 ℓ	
NET WEIGHT		J147/J127		B147/B127	
		78 kg		75 kg	
WASH AND DRY CAPACITY	WASH	7.0 kg (DRY LAUNDRY)		6.0 kg (DRY LAUNDRY)	
	DRY	3.5 kg(DRY LAUNDRY)		3.0 kg(DRY LAUNDRY)	
POWER CONSUMPTION	MODEL	J147/J127		B147/B127	
	WASHING	230 W	150 W	230 W	150 W
	WASHING AND HEATING	220 V	2000 W	220 V	2000 W
		240 V	2400 W	240 V	2400 W
	DRY	220 V	2000 W	220 V	2000 W
		240 V	2400 W	240 V	2400 W
	PUMPING	34 W			
SPIN REVOLUTION	MODEL	J147/J127		B147/B127	
PACKAGE Wt	PAPER	2.5 kg		2.5 kg	
	PLASTIC	1.0 kg		1.0 kg	
LOAD	MODEL	J147/B147		J127/B127	
	rpm	1400		1200	



Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

SAMSUNG

دستورالعمل هاي دارنده ماشين لباسشويي

J147(W/V/C/S/R)

J127(W/V/C/S/R)

B147(W/V/C/S/R)

B127(W/V/C/S/R)



محصول خود را در

www.samsung.com/global/register ثبت کنید

شماره کُد: DC68-02410N_FA

۱. **Silver Wash** (شستشوی نقره ای) (Ag^+)
ویژگی نانو نقره ای Samsung از ذرات نانو نقره ای استفاده می کند تا لباس ها و استوانه ماشین را بهداشتی و ضد عفونی کند. جوارب های ظریف و یا بدبو در درجه حرارت هایی که به پایینی ۳۰ درجه هستند از بوی عرق بدن زوده می شوند. این موضوع موجب صرفه جویی در مصرف انرژی شده و از رنگ و شکل لباس های شما محافظت می کند.
۲. **Child Lock** (قفل کودک)
عملکرد قفل کودک، دست های کوچک کنجکاو را از ماشین لباسشویی دور نگه می دارد. این عملکرد ایمنی همچنین تضمین می کند که کودکان با کنترل های ماشین لباسشویی بازی نکنند. همچنین هنگامیکه فعال شده به شما هشدار می دهد.
۳. **Delay Start** (تأخیر در شروع)
این عملکرد به استفاده کننده از ماشین رختشویی امکان می دهد تا وقت شروع را تا حداکثر ۲۴ ساعت به تأخیر بیاورد.
۴. **Calm Wash** (شستشوی آرام)
ما یک چرخه شستشو داریم که آنقدر ساکت است که می توانید در هنگام خواب لباسشویی کنید. این چرخه گردش در حین تخلیه آب بسیار ساکت است.
۵. **Less Ironing** (اتو کشنی کمتر)
نیاز به اتو کشنی کمتر است چون Carefreewash (شستشوی بی دردسر) Samsung لباس های نرم و ظریف و پارچه هایی که به آسانی تمیز می شوند را با اطمینان تمیز می کند. عملکرد اتو کشنی کمتر که توسط فناوری روند دیجیتال Samsung که شهرت جهانی دارد تهیه و تولید شده یک برنامه ویژه لباسشویی است که چروکیدگی لباس های ظریف را کاهش داده و وقتی که برای اتو کشنی صرف می کنید را کاهش می دهد.
۶. **Delicates & Wool** (لباس های ظریف و پشمی)
مراقبت ویژه را می توان توسط دمای مناسب، عمل شستشوی ملایم و مقدار مناسب آب مشخص کرد.
۷. **Air Wash** (شستشوی با هوا)
سیستم شستشو با هوا بوهایی ناخوشایند را بوزدایی کرده و «باکتری» و مایت ها را در لباس ضد عفونی می کند که نمی توان از طریق سیستم شستشوی متعارف از بین برد. مزیت مکانیزم منحصر به فرد شستشو با هوا:
• قابل شستشو با هوا: کت های پشمی، روپوش های نخی/پری، ژاکت، کت و شلوار، بالش، کوسن، عروسک های سوزن دوزی
• مربوط نمی شود: چرم، ابریشم، مخمل، پنبه برقی، لباس کشیف دیگر

از اینکه ماشین رختشویی Samsung را خریداری کردید به شما تبریک می گوئیم. این دستورالعمل های دارنده حاوی اطلاعات ارزشمندی در مورد نحوه نصب، استفاده و مراقبت از این دستگاه است. لطفاً برای خواندن این دستورالعمل ها وقت بگذارید تا بتوانید به طور کامل از خواص این ماشین لباسشویی بهره مند شده و برای سالها از این دستگاه بهره مند شوید.

قبل از استفاده از این دستگاه

- مواد بسته بندی می توانند برای کودکان خطرناک باشند؛ همه مواد بسته بندی (کیسه های پلاستیکی، پلی استیرن و غیره) را کاملاً از دسترس کودکان دور نگه دارید.
- این دستگاه صرفاً برای استفاده در خانه طراحی شده است.
- مطمئن شوید که اتصالی های آب و برق توسط تکنسین های مجرب برقرار شوند که دستورالعمل های سازنده (به «نصب ماشین لباسشویی» رجوع شود) و مقررات ایمنی محلی را مراعات می کنند.
- همه پیچ های بسته بندی و حمل و نقل را بایستی قبل از استفاده از دستگاه جدا کرد. اگر جدا نشوند ممکن است موجب صدمه جدی شوند. به «جدا کردن پیچ های حمل و نقل» رجوع شود.
- قبل از نشتن لباس ها برای بار اول، بایستی یک چرخه کامل را بدون قرار دادن لباس اجرا کنید. به «شستشو برای اولین بار» رجوع شود.

دستورالعمل های ایمنی

- قبل از تمیز کردن ویا اجرای تعمیر و نگه داری، دستگاه را از پریز برق بیرون کشیده ویا دکمه ⑤ (روشن/خاموش) را خاموش کنید.
- مطمئن شوید که جیب های همه رخت هایی که شسته می شوند خالی شده باشند. اشیاء سخت و نیز از قبیل سکه، سنجاق قفلی، میخ، پیچ ویا سنگ ممکن است به این دستگاه صدمه جدی بزنند.
- همیشه بعد از استفاده، سیم دستگاه را از برق بکشید و آب را ببندید.
- قبل از باز کردن دریچه دستگاه، کنترل کنید که آب تخلیه شده باشد. اگر هنوز آب می بینید، دریچه را باز نکنید.
- حیوانات خانگی و کودکان خردسال ممکن است به داخل دستگاه بروند. دستگاه را قبل از استفاده کنترل کنید.
- دریچه شیشه ای در حین چرخه شستشو بسیار داغ می شود. در حین استفاده، کودکان را از دستگاه دور نگه دارید.
- سعی نکنید که دستگاه را خودتان تعمیر کنید. تعمیراتی که توسط اشخاص بی تجربه ویا فاقد صلاحیت انجام شود ممکن است موجب صدمه شخصی شده ویا تعمیرات جدی تر دستگاه لازم شود.
- اگر دوشاخه (سیم جریان برق) صدمه دیده، بایستی توسط سازنده ویا تعمیرکار ویا شخص مجرب مشابه دیگری تعویض شود تا از خطر جلوگیری شود.
- تنها مرکز تعمیر مجاز بایستی این دستگاه را تعمیر کرده و تنها بایستی از قطعات یدکی اصلی استفاده شود.
- این دستگاه برای استفاده توسط کودکان خردسال ویا اشخاص علیل درست نشده مگر اینکه به طور مناسب توسط یک فرد مسئول نظارت شده باشند تا مطمئن شوید که می توانند به طور امن از آن استفاده کنند.
- بایستی از کودکان خردسال نظارت کرد تا مطمئن شوید که با دستگاه بازی نمی کنند.
- اگر به همراه این دستگاه یک مجموعه سیم رابط ویا یک وسیله پریز برق قابل حمل تأمین شده، مجموعه سیم رابط ویا وسیله پریز برق قابل حمل بایستی طوری قرار داده شوند که در معرض آب پاشی ویا وارد شدن رطوبت قرار نگیرند. علاوه بر این، مجموعه سیم رابط ویا وسیله پریز برق قابل حمل بایستی از نوع جریان برقی باشند که برای دستگاه مناسب است.
- این دستگاه بایستی به پریز وصل شود که قدرت تحمل مصرف نیروی مناسب را داشته باشد.
- این دستگاه بایستی طوری قرار داده شود که پریز بعد از نصب قابل دسترسی باشد.
- از آب فرایند شده حاوی روغن، کرم یا لوسیون استفاده نکنید که معمولاً در فروشگاه های مراقبت از پوست ویا کلینیک های ماساژ یافت می شوند.
- در غیراینصورت باعث خواهد شد که بسته بندی تغییر شکل داده که موجب خراب کار کردن ویا نشت آب می شود.
- یک نشت شستشوی ضدزنگ معمولاً زنگ نمی زند. با این وجود اگر بعضی فلزات از قبیل گیره مو برای مدت طولانی در تشت باقی ماند، ممکن است زنگ بزنند.
- آب ویا مواد رنگبر حاوی کلر را نگذارید برای مدت طولانی در تشت باقی بماند.
- از آب حاوی آهن به طور دائم و طولانی مدت در تشت استفاده نکرده ویا نگذارید باقی بماند.
- اگر زنگ زدگی بر روی سطح تشت شروع به پدیدار شدن کند، یک محلول تمیز کننده (اختی) به سطح مالید و از یک اسفنج ویا پارچه نرم برای تمیز کردن آن استفاده کنید. (اخت هیچ شرایطی از برس فلزی استفاده نشود)
- برای ماشین های لباسشویی که روزنه های هواگیرشان در زیر است، زمین مغروش نیابستی این روزنه ها را مسدود کند.
- از مجموعه لوله های جدید استفاده کنید و نیابستی از مجموعه لوله های قدیمی دوباره استفاده نشود.


احتیاط‌های ایمنی	داخل جلد
نصب ماشین لباسشویی	A-۱
خارج کردن ماشین لباسشویی از بسته	A-۱
مرور ماشین لباسشویی	A-۱
انتخاب یک محل	A-۲
تنظیم پایه‌های تراز کردن	A-۲
جدا کردن پیچ‌های حمل و نقل	A-۲
وصل کردن لوله تأمین آب	A-۳
قرار دادن لوله تخلیه	A-۶
شنستشوی مقداری لباس	B-۱
مرور پل کنترل	B-۱
شنستشوی لباس‌ها با استفاده از Fuzzy Logic	B-۳
شنستشوی لباس‌ها به‌طور دستی	B-۶
استفاده از تأخیر در شروع	B-۶
شنستشو برای بار اول	B-۵
گذاشتن پودر لباسشویی در داخل ماشین لباسشویی	B-۵
ره‌نمودها و راهنمایی‌های شنستشو	B-۶
حفظ و نگه‌داری از ماشین لباسشویی	C-۱
تخلیه آب ماشین لباسشویی در موقعیت اضطراری	C-۱
تعمیر یک ماشین لباسشویی یخ‌زده	C-۱
تمیز کردن سطح بیرونی	C-۱
تمیز کردن کشو و حفره پودر لباسشویی	C-۲
تمیز کردن فیلتر کثافات	C-۲
تمیز کردن فیلتر توری لوله آب	C-۳
عیب‌یابی	D-۱
مشکلات و راه‌حل‌ها	D-۱
شناسایی پیغام‌های خطا	D-۱
جدول برنامه	E-۱
ضمیمه	F-۱
جدول مراقبت از پارچه	F-۱
اخطارهای برقی	F-۱
محافظة از زیست محیط	F-۲
اعلامیه سازگاری	F-۲
مشخصات	F-۲

نصب ماشین لباسشویی

خارج کردن ماشین لباسشویی از بسته

ماشین لباسشویی را از بسته خارج کرده و بازبینی کنید که در حین حمل و نقل آسیب ندیده باشد. همچنین مطمئن شوید همه اقلامی که در زیر نشان داده شده را دریافت کرده اید. اگر در حین حمل و نقل به ماشین لباسشویی صدمه وارد شده و همه اقلام را ندارید، فوراً با فروشنده Samsung خود تماس بگیرید.

مرور ماشین لباسشویی




نصب ماشین لباسشویی

انتخاب یک محل

- قبل از نصب ماشین لباسشویی، محلی که خصوصیات زیر را دارد انتخاب کنید:
- یک سطح محکم و هم تراز (اگر سطح ناهموار است، به «تنظیم پایه های تراز کردن» در زیر رجوع شود)
 - به دور از نور مستقیم خورشید.
 - هواگیری کافی
 - دمای اتاق که پایین تر از ۰ درجه سانتی گراد نخواهد رفت.
 - به دور از منابع گرما از قبیل ذغال سنگ ویا گاز
- مطمئن شوید که ماشین لباسشویی را بر روی سیم برقش نگذارید.
- روزنه های هواگیر را نبایدستی در حالیکه ماشین لباسشویی بر روی یک زمین مفروش گذاشته شده توسط فرش مسدود کرد.

تنظیم پایه های تراز کردن




اگر کف اتاق ناهموار است، پایه ها را تنظیم کنید (قطعه های چوب ویا هرگونه اشیاء دیگر را به زیر پایه ها وارد نکنید):

۱. پیچ پایه را توسط چرخاندن با دست شل کنید تا اینکه به بلندی مورد نظر برسد.
۲. مهره قفل کردن آن با چرخاندن آن توسط آچار تأمین شده محکم کنید.

اگر ماشین بر روی یک سطح ناهموار ویا سست قرار داده شود، موجب سروصدا و لرزش می شود.

(تنها زاویه ۱ درجه مجاز است.)

جدا کردن پیچ های حمل و نقل



قبل از استفاده از ماشین لباسشویی، بایستی پیچ حمل و نقل را از پشت دستگاه جدا کنید. برای جدا کردن پیچ ها:

۱. همه پیچ ها را قبل از باز کردن با آچار تأمین شده شل کنید.
۲. سر هر پیچ را گرفته و آنرا از داخل قسمت پهن سوراخ بکشید.
- این کار را برای هر پیچ تکرار کنید.
۳. سوراخ ها را با پوشش های پلاستیکی تأمین شده پر کنید.
۴. پیچ های حمل و نقل را برای استفاده در آینده نگه دارید.


نصب ماشین لباسشویی

وصل کردن لوله تأمین آب

لوله تأمین آب بایستی از یک طرف به ماشین لباسشویی و از طرف دیگر به شیر آب متصل شود. لوله تأمین آب را نکشید. اگر لوله آب زیادی کوتاه است، آنرا با لوله بلندتر فشار زیاد تعویض کنید.

برای اتصال لوله تأمین آب:

۱. قطعه به شکل A برای لوله تأمین آب سرد را گرفته و آنرا به ورودی تأمین آب سرد در پشت ماشین متصل کنید. با دست محکم کنید.
۲. سر دیگر لوله تأمین آب سرد را به شیر آب سرد ظرفشویی متصل کرده و با دست محکم کنید. در صورت لزوم، می توانید لوله تأمین آب را با شل کردن قطعه در طرف ماشین لباسشویی و محکم کردن قطعه سر جایش بگذارید.





گرمش:

۱. قطعه به شکل A قرمز برای لوله تأمین آب گرم را گرفته و آنرا به ورودی تأمین آب گرم فرمزد در پشت ماشین متصل کنید. با دست محکم کنید.
۲. سر دیگر لوله تأمین آب گرم را به شیر آب گرم ظرفشویی متصل کرده و با دست محکم کنید.
۳. اگر می خواهید فقط از آب سرد استفاده کنید از یک قطعه Y استفاده کنید.

نصب ماشین لباسشویی

وصل کردن لوله تأمین آب (انتخابی)

۱. آداپتور را از لوله تأمین آب جدا کنید.		۴. لوله تأمین آب را به آداپتور وصل کنید. بخش (c) لوله تأمین آب را پایین کشیدم هنگامیکه بخش (c) را رها می کنید. لوله به طور خودکار به آداپتور وصل شده صدای «کلیک» می کند.	
۲. ابتدا با استفاده از پیچ گوهی نوع «۴» چهار پیچ روی آداپتور را شل کنید. سپس آداپتور را گرفته و قسمت (b) را در جهت پیکان گردانده تا اینکه یک شکاف ۵ میلی متری به وجود بیاید.		۵. سر دیگر لوله تأمین آب را به سرپیچ منبع آب در پشت ماشین متصل کنید. لوله را تا آخر به داخل در جهت عقربه ساعت پیچ کنید.	
۳. آداپتور را با محکم کردن پیچ ها به شیر آب وصل کنید. سپس قسمت (b) را در جهت پیکان بچرخانید و قسمت (a) و (b) را روی هم بگذارید.			


توجه بعد از اینکه اتصال کامل شد، اگر آب از لوله نشت می کند، همان مراحل را تکرار کنید. از نوع شیری که برای تأمین آب بیشتر معمول است استفاده کنید. در صورتیکه شیر چهارگوش ویا زبانی بزرگ است، حلقه فاصله بندی را قبل از وارد کردن شیر به داخل آداپتور جدا کنید.

قرار دادن لوله تخلیه

آخر لوله تخلیه را می توان به سه طریق قرار داد:

بر روی لبه ظرفشویی

لوله تخلیه بایستی به بلندی بین ۶۰ و ۹۰ سانتی متر قرار داده شود. برای کج نگه داشتن دهانه لوله، از راهنمای لوله پلاستیکی تأمین شده استفاده کنید. راهنما را به وسیله یک قلاب به دیوار ویا به وسیله یک قطعه ریسمان به شیر محکم کنید تا از حرکت لوله تخلیه جلوگیری شود.



در یک شاخه لوله تخلیه ظرفشویی


شاخه لوله تخلیه بایستی در بالای سیفون ظرفشویی قرار داشته باشد تا انتهای لوله حداقل ۶۰ سانتی متر بالای سطح زمین باشد.

در یک لوله تخلیه

Samsung توصیه می کند که از یک لوله عمودی به درازای ۶۵ سانتی متر استفاده کنید؛ بایستی کوتاه تر از ۶۰ سانتی متر و بلندتر از ۹۰ سانتی متر نباشد.

شستشوی مقداری لباس

مرور پنل کنترل




۱. نمایشگر گرافیک دیجیتال زمان باقی مانده چرخه شستشو. همه اطلاعات شستشو و پیغام های خطا را نشان می دهد.
۲. دکمه گزینش Air Wash (شستشو با هوا)
این دکمه را مکرراً فشار دهید تا در بین عملکردهای بوزایی و ضد عفونی چرخ بزنید. هنگامیکه عملکرد شستشو با هوا انتخاب شده، نمی توان از چرخه های دیگر استفاده کرد. بوزایی: بوهایی بد را از لباس می گیرد
ضد عفونی: باکتری و مایت ها را از لباس بیرون می کشد
۳. دکمه انتخاب Silver Nano (Ag+) (ضد عفونی، «محافظت»، «ضد عفونی»، «محافظت» را انتخاب کنید)
آب Silver Nano در شستشو به همراه آخرین آبکشی تأمین شده که ضد عفونی و پوشش ضد باکتری را عرضه می کند. (می توانید «ضد عفونی» یا «محافظت»، «ضد عفونی»، «ضد عفونی» را انتخاب کنید)
۴. دکمه انتخاب Pre-wash+ (پیش شستشو+)
برای انتخاب پیش شستشو این دکمه را فشار دهید. پیش شستشو تنها برای الیاف نخی، رنگی، مصنوعی، بسیار کثیف، موجود است.
۵. دکمه انتخاب Drying Time (مدت خشک شدن)
این دکمه را مکرراً فشار دهید تا در بین گزینش های خشک کردن موجود چرخ بزنید. (۱۲۰ دقیقه → ۹۰ دقیقه → ۶۰ دقیقه → ۳۰ دقیقه)
۶. دکمه انتخاب Intensive (شدید)
هنگامیکه انتخاب شود، قدرت شستشو افزایش پیدا می کند. از این عملکرد می توان برای برنامه های نخی، رنگی، مصنوعی، جین، بسیار کثیف، لباس های مخلوط و شستشوی آرام استفاده کرد. فشردن این دکمه بین روشن و خاموش تغییر می کند.
۷. دکمه انتخاب Temperature (دما)
این دکمه را مکرراً فشار دهید تا بین گزینش های دمای آب چرخ بزنید. (سرد → درجه سانتی گراد، ۳۰، ۴۰، ۶۰ و ۹۵ درجه سانتی گراد)
دمای پیش فرض بستگی به چرخه متفاوت است. می توانید یک دمای لباسشویی خاص را از بین گزینش های دمای از قبل تنظیم شده انتخاب کنید.
۸. دکمه انتخاب Rinse (آبکشی)
دکمه آبکشی را برای افزودن چرخه های آبکشی فشار دهید. حداکثر تعداد چرخه های آبکشی پنج است.
۹. دکمه انتخاب Spin (چرخش)
این دکمه را مکرراً فشار دهید تا در بین گزینش های سرعت چرخش موجود چرخ بزنید.

J147/B147	نگه داشتن آبکشی، بدون چرخش (۰)، ۴۰۰، ۸۰۰، ۱۲۰۰، ۱۴۰۰ دور در دقیقه
J127/B127	نگه داشتن آبکشی، بدون چرخش (۰)، ۴۰۰، ۸۰۰، ۱۲۰۰ دور در دقیقه

• بدون چرخش بدون نمایش: نگه داشتن آبکشی

شنسشنوي مقداري لباس



۱۰. **دکمه انتخاب Delay Start (تاخیر در شروع)**
این دکمه را مکرراً فشار دهید تا در بین گزینش های تاخیر در شروع چرخ برزید (از ۳ تا ۱۹ ساعت به فواصل یک ساعته). ساعات نشان داده شده به معنی وقت چرخه شنسشنوي است که تمام شده.
۱۱. **دکمه انتخاب Less Ironing (اتوکشني کمتر)**
اتوکشني کمتر چروکیدگي و مدت اتوکشني را کاهش خواهد داد. (برنامه موجود: نخي، رنگي، مصنوعي، جين، سريع، بسيار کصيف، لباس هاي مخلوط، آبکشني + چرخش، چرخش)
۱۲. **دکمه گزینش Child Lock (قفل کودک)**
این دکمه برای جلوگیری از دستکاری ماشین لباسشویی توسط کودکان است.
روشن/خاموش - برای روشن کردن برنامه: دکمه Start/Pause (شروع/مکث) را برای روشن کردن ماشین لباسشویی فشار دهید. دکمه (Temp) + (Intensive) (شدید + دما) را برای ۲ تا ۳ ثانیه فشار داده و نگه دارید. تنها زمانیکه ماشین روشن شده می تواند فعال شود. هنگامیکه Child Lock (قفل کودک) را در حال شنسشنوي روشن می کنید، تا زمانیکه آنرا خاموش کنید دکمه ای فعال نمی شود. حتی دکمه POWER (نیرو) فعال نخواهد شد. چراغ Child Lock (قفل کودک) روشن می شود. برای خاموش کردن برنامه: دکمه (Temp) + (Intensive) (شدید + دما) را برای ۲ تا ۳ ثانیه فشار داده و نگه دارید. سپس چراغ خاموش شده و خاموش می شود.
تذکر: هنگامیکه در حالیکه ماشین لباسشویی کار می کند دکمه ای فعال نشده، ابتدا Child Lock (قفل کودک) را کنترل کنید
۱۳. **تکمه کنترل Fuzzy (مبهم)**
تکمه را برای انتخاب ۱۲ برنامه شنسشنوي موجود بگردانید.
نخي، رنگي، مصنوعي، پارچه هاي ظرف، شنسشنوي با دست برای پشمي، جين، سريع، خشك کردن، بسيار کثيف، لباس هاي مخلوط، شنسشنوي آرام تخلیه، چرخش، آبکشني + چرخش
۱۴. **دکمه انتخاب Start/Pause (شروع/مکث)**
دکمه Start/Pause (شروع/مکث) را برای متوقف کردن و یا شروع دوباره یک چرخه فشار دهید. اگر می خواهید چرخه شنسشنوي را در حال اجرای یک چرخه تغییر دهید. این دکمه را برای متوقف کردن چرخه در حال اجرا فشار داده و آنرا برای شروع دوباره ماشین لباسشویی بعد از انتخاب یک چرخه دیگر فشار دهید.
۱۵. **دکمه انتخاب (روشن/خاموش)**
برای روشن کردن ماشین لباسشویی یک بار فشار دهید. برای خاموش کردن ماشین لباسشویی دوباره فشار دهید. اگر ماشین لباسشویی به مدت ۱۰ دقیقه بدون اینکه دکمه ای فشرده شود روشن باقی ماند، ماشین به طور خودکار خاموش می شود.

شنسشنوي مقداري لباس


شنسشنوي لباس ها با استفاده از Fuzzy Logic

ماشين لباسشويي جديد شما شنسشنوي لباس ها را با استفاده از سيستم كنترل خودكار "Fuzzy Logic" از Samsung آسان مي كند. هنگاميكه يك برنامه شنسشنو را انتخاب مي كنيد، ماشين دماي صحيح، زمان شنسشنو و سرعت شنسشنو را تنظيم مي كند.

براي شنسشنوي لباس ها با استفاده از برنامه هاي Fuzzy Logic:

۱. شير آب ظرفشويي خود را باز كنيد.
۲. دكمه (روشن/خاموش) (⏻) را فشار دهيد.
۳. دريچه را باز كنيد.
۴. لباس ها را به طور جداگانه و سوا وارد استوانه گردان كنيد بدون اينكه زيادي پر شود.
۵. دريچه را ببنديد.
۶. پودر لباسشويي، نرم كننده و (در صورت لزوم) ماده پيش شنسشنو را در محفظه مناسب بريزيد.
۷. تكمه Fuzzy Control (كنترل مبهم) را بگردانيد تا برنامه مناسب را براي نوع لباس هاي Cotton (الياف نخی)، Coloureds (رنگي)، Synthetics (مصنوعي)، Hand Wash For Delicate Fabrics (پارچه هاي ظريف)، Wool (شنسشنو با دست براي پشمي)، Jeans (جين)، Quick (سريع)، Drying (خشك كردن)، Heavy Soil (بسيار كثيف)، Mixed Load (لباس هاي مخلوط)، Calm Wash (شنسشنوي آرام)، Drain (تخليه)، Spin (گردش)، Rinse+Spin (آبكشي، گردش) را انتخاب كنيد.

مشاهده خواهيد كرد كه نشانگرها بر روي پنل كنترل روشن مي شوند.



۸. در اين زمان، مي توانيد با فشردن دكمه گزينش مناسب دماي شنسشنو، مدت آبكشي، سرعت چرخش، مدت تاخير را كنترل كنيد.
۹. دكمه Start/Pause را بر روي تكمه Fuzzy Control فشار داده و چرخه شنسشنو شروع خواهد شد. نشانگر روند روشن خواهد شد و مدت باقي مانده براي چرخه بر روي نمايشگر ظاهر خواهد شد.

گزينش Pause (مكت) (عملكرد توقف و اضافه كردن رخت)

در ظرف ۵ دقيقه از شروع، مي توان لباس ها را اضافه ويا خارج كرد.

اگر دكمه Start/Pause (شروع/مكت) را فشار دهيد، قفل دريچه به طور خودكار باز مي شود.

اگر آب زيادي گرم بوده ويا آب زيادي در ماشين لباسشويي باشد، نمي توان دريچه را باز كرد.

پس از بستن دريچه، يك فشار ديگر دكمه Start/Pause (شروع/مكت) موجب مي شود كه روال شنسشنو به طور متداوم ادامه پيدا كند.

هنگاميكه چرخه تمام شد:

بعد از اينكه كل چرخه تمام شد، ماشين به طور خودكار خاموش خواهد شد.

۱. دريچه را باز كنيد.
۲. رخت ها را خارج كنيد.

شنسشنوي مقداري لباس

شنسشنوي لباس ها به طور دستي

مي توانيد لباس ها را بدون استفاده از ويژگي Fuzzy Logic به طور دستي بشنوبيد.

براي اتمام اينكار:

۱. منبع آب را باز كنيد.
۲. دكمه (روشن/خاموش) را بر روي ماشين لباسشويي فشار دهيد.
۳. دريچه را باز كنيد.
۴. لباس ها را به طور جداگانه و سوا وارد استوانه گردان كنيد بدون اينكه زيادي پر شود.
۵. دريچه را ببنديد.
۶. پودر لباسشويي و در صورت لزوم نرم كننده و ماده پيش شنسشنو را در محفظه هاي مناسب بگذاريد.
۷. دكمه Temperature (دما) را براي انتخاب دما فشار دهيد.
(سرد -۱ درجه سانتي گراد). ۳۰، ۴۰، ۶۰ و ۹۵ درجه سانتي گراد)
۸. دكمه آبكشي را براي انتخاب تعداد لازم چرخه هاي آبكشي فشار دهيد.
حداكثر دفعات چرخه هاي آبكشي پنج است.
طول شنسشنو به همان ترتيب محدود خواهد شد.
۹. دكمه Spin (گردش) را براي انتخاب سرعت چرخش فشار دهيد. [۴۰۰، ۸۰۰، ۱۲۰۰ يا ۱۴۰۰ دور در دقيقه (rpm)]
توجه: برنامه نگه داشتن آبكشي به شما امكان مي دهد لباس هايي كه كاملاً خيس هستند را از ماشين لباسشويي خارج كنيد
۱۰. بدون چرخش. بدون نمايش: نگه داشتن آبكشي
۱۱. اين دكمه را مكرراً فشار دهيد تا در بين گزينش هاي تاخير در شروع چرخ بزنيد (از ۳ تا ۱۹ ساعت به فواصل يك ساعته). ساعات نشان داده شده به معني وقت چرخه شنسشنويي است كه تمام شده.
۱۱. دكمه Start/Pause (شروع/مكت) را فشار دهيد و ماشين چرخه را شروع خواهد كرد.

استفاده از تاخير در شروع

مي توانيد ماشين رختشويي را طوري تنظيم كنيد كه بعداً شنسشنو را تمام كند. تاخير بين ۳ تا ۱۹ ساعت را مي توان انتخاب كرد (در فواصل ۱ ساعته). ساعات نشان داده شده به معني وقت چرخه شنسشنويي است كه تمام شده.


براي اتمام اينكار:

۱. ماشين لباسشويي را به طور دستي ويا خودكار براي نوع لباس هايي كه مي شوييد تنظيم كنيد.
۲. دكمه Delay Start (تاخير در شروع) را مكرراً فشار دهيد تا مدت تاخير تنظيم شود.
۳. دكمه Start/Pause (شروع/مكت) را فشار دهيد. نشانگر Delay Start (تاخير در شروع) روشن خواهد شد و ساعت شروع به شمارش معكوس مي كند تا به زمان پايان برسد.
۴. براي لغو كردن Delay Start (تاخير در شروع)، دكمه (روشن/خاموش) را فشار داده سپس ماشين لباسشويي را دوباره روشن كنيد.

شستشوی مقداری لباس

شستشو برای بار اول

قبل از شستن لباس ها برای بار اول، بایستی یک چرخه کامل را بدون قرار دادن لباس اجرا کنید.
برای اتمام اینکار:



۱. دکمه (روشن/خاموش) (I) را فشار دهید.
۲. کمی پودر لباسشویی را در محفظه (II) در کشوی پودر لباسشویی بریزید.
۳. منبع آب به ماشین لباسشویی را باز کنید.
۴. دکمه Temperature (دما) را مکرراً فشار دهید تا ۴۰ درجه سانتی گراد نمایان شود.
۵. دکمه Start/Pause (شروع/مکث) را فشار دهید.
- چنین کاری هرگونه آب که از اجرای آزمایش سازنده ماشین در آن باقی مانده را تخلیه خواهد کرد.

محفظه ①: پودر لباسشویی برای پیش شستشو ویا آهار.

محفظه ②: پودر لباسشویی برای شستشوی اصلی نرم کننده آب، عامل پیش خیساندن، ماده رنگبرو محصول پاک کردن لکه.


محفظه ③: مواد افزودنی از قبیل نرم کننده پارچه ویا فرم دهنده (بیشتر از لبه پایین تر ورودی "A" پر نکنید)

گذاشتن پودر لباسشویی در داخل ماشین لباسشویی

۱. کشوی پودر لباسشویی را بیرون بکشید.
۲. پودر لباسشویی را به محفظه اضافه کنید ②.
۳. نرم کننده را به محفظه اضافه کنید ③ (اگر مایلید).
۴. پودر لباسشویی پیش شستشو را به محفظه اضافه کنید ① (اگر مایلید).

احتیاط:

نرم کننده پارچه و حالت دهنده هم فشرده ویا غلیظ بایستی قبل از اینکه به داخل محفظه ریخته شود با کمی آب رقیق شوند (از مسدود شدن مخرج لبریز جلوگیری می کند).



شنسشنوي مقداري لباس

رهنمودها و راهنمايي هاي شنسشنو

- دسته بندي لباس ها: لباس هاي خود را بر طبق خصوصيت هاي زير دسته بندي كنيد:
- نوع علامت برچسب مراقبت پارچه: لباس ها را بر طبق الياف نخي، پارچه هاي مخلوط، مصنوعي، ابريشمي، پشمي و رايون دسته بندي كنيد.
- رنگ: سفيد ها و رنگي ها را جدا كنيد. اقلام رنگي نو را جداگانه بشوييد.
- اندازه: قرار دادن اقلام به اندازه هاي مختلف در يك توده عمل شنسشنو را بهبود خواهد داد.
- ظرافت: اقلام ظريف را با استفاده از برنامه شنسشنوي Delicate (ظريف) براي اقلام پشمي خالص نو، پرده و ابريشمي به طور جداگانه بشوييد. برچسب هاي اقلامي كه مي شنوييد را كنترل كنيد ويا به جدول مراقبت پارچه در ضميمه رجوع كنيد.
- خالي كردن جيب ها: سكه، سنجاق قفلي و اقلام مشابه ممكن است به ملافه، استوانه گردان ماشين لباسشويي و تانك آب صدمه بزنند.
- محكم كردن دكمه ها و زيپ ها: زيپ ها را ببنديد و دكمه ها ويا قلابها را محكم كنيد: كمربندها ويا نوارهاي آويزان بايستي به هم گره بخورند.
- پيش شنسشنوي الياف نخي: ماشين لباسشويي جديد شما به همراه پودرهاي شنسشنوي مدرن نتايج عالي شنسشنو خواهد داد و بنابراین در مصرف انرژي، وقت، آب و پودر لباسشويي صرفه جويي مي شود. با اين وجود، اگر الياف نخي بسيار كثيف مي باشند، از پيش شنسشنو با يك پودر لباسشويي براساس پروتئين استفاده كنيد.
- مشخص كردن ظرفيت شنسشنو: ماشين لباسشويي را زيادي پر نكنيد. در غير اينصورت لباس ها ممكن است به خوبي شسته نشوند. از جدول زير براي مشخص كردن ظرفيت شنسشنو براي نوع لباس هايي كه مي شنوييد استفاده كنيد.

ظرفيت شنسشنو		نوع پارچه
B147/B127	J147/J127	
نخي/رنگي	۷/۰ كيلوگرم	۶/۰ كيلوگرم
مصنوعي	۳/۰ كيلوگرم	۳/۰ كيلوگرم
ظريف	۲/۵ كيلوگرم	۲/۵ كيلوگرم
شنسشنو با دست براي الياف پشمي	۱/۰ كيلوگرم	۱/۰ كيلوگرم

رهنمودهاي پودر رختشويي: نوع پودر لباسشويي كه استفاده مي كنيد بايستي براساس نوع پارچه (نخي، مصنوعي، اقلام ظريف، شنسشنو با دست براي الياف پشمي)، رنگ، دماي شنسشنو، مقدار و نوع كثيفي باشد.


هميشه از صابون لباسشويي «كم كف» استفاده كنيد كه براي ماشين هاي لباسشويي خودكار طراحي شده است.

توصيه هاي سازنده پودر لباسشويي را براساس وزن لباس ها، ميزان كثيفي و سختي آب در منطقه تان دنبال كنيد. اگر نمي دانيد كه سختي آب به چه اندازه است، از سازمان مسئول آب استوال كنيد.


توجه: پودر لباسشويي و ماده هاي افزودني را در يك محل امن و خشك كه در دسترس كودكان نيست نگه داريد.

حفظ و نگه داري از ماشين لباسشويي

تخليه آب ماشين لباسشويي در موقعيت اضطراري



۱. دوشاخه ماشين لباسشويي را از پريز بکشيد.
۲. پوشش فيلتر را با استفاده از يك سكه يا كليد باز كنيد.



۳. سريوش تخليه اضطراري را با گرداندن به سمت چپ باز كنيد. سريوش در پايين لوله تخليه اضطراري را گرفته و آنرا در حدود ۱۵ سانتي متر به آهستگي بيرون بکشيد.

۴. اجازه بدهيد كه همه آب به داخل كاسه روان شود.
۵. لوله تخليه را دوباره وارد كرده و سريوش را سرجايش پيچ كنيد.
۶. پوشش فيلتر را سرجايش بگذاريد.

تعمير يك ماشين لباسشويي يخ زده

اگر درجه حرارت به زير دماي انجماد افت كند و ماشين لباسشويي منجمد شود:

۱. ماشين لباسشويي را از پريز بکشيد.
۲. آب گرم را بر روي شمير منيع بريزيد تا لوله منيع آب شل شود.
۳. لوله منيع آب را جدا كرده و آنرا در آب گرم بخيسانيد.
۴. آب گرم را به داخل استوانه گردان ماشين لباسشويي جاري كرده و اجازه بدهيد كه براي ۱۰ دقيقه باقي بماند.
۵. لوله منيع آب را دوباره به شمير آب متصل كرده و كنترل كنيد كه منيع آب و عملكرد تخليه عادي باشند.




تميز كردن سطح بيروني

۱. سطوح بيروني ماشين لباسشويي كه شامل پتل كنترل مي شود را با يك پارچه نرم و محلول شستشوي ناساينده خانگي تميز كنيد.
۲. براي خشك كردن سطوح بيروني از يك پارچه نرم استفاده كنيد.
۳. بر روي ماشين لباسشويي آب جاري نكنيد.

حفظ و نگه داري از ماشين لباسشويي

تميز کردن كشنو و حفره پودر لباسشويي

۱. اهرم رها كننده در داخل كشنوي پودر لباسشويي را فشار داده و آنرا به بيرون بکشيد.
۲. سريوش را از روي محفظه برداريد. 
۳. همه قطعات را زير آب جاري بشوييد.
۴. حفره كشنو را با يك مسواك كه نه تميز كنيد.
۵. سريوش را دوباره وارد كرده (آترا محكم سرجايش فشار دهيد) و جداكننده ماده لباسشويي مابع را سرجايش در داخل كشنو بگذاريد.
۶. كشنو را سرجايش فشار دهيد.
۷. يك برنامه آبكشي را بدون اينكه لباسي در استوانه گردان باشد اجرا كنيد.





تميز کردن فيلتر كفافات

فيلتر كفافات را ۵ يا ۶ بار در سال تميز كنيد ويا هنگاميكه پيغام خطاي زير را در نمايشگر مي بينيد:

5E

۱. پوشش فيلتر را باز كنيد. به «تخليه ماشين رختشويي در موقعيت اضطراري» در صفحه ۱-C رجوع شود.
۲. سريوش تخليه اضطراري را با چرخاندن آن به سمت چپ باز كرده و همه آب را تخليه كنيد.
۳. به «تخليه ماشين رختشويي در موقعيت اضطراري» در صفحه ۱-C رجوع شود. سريوش فيلتر را باز كرده و آنرا خارج كنيد.



۴. هرگونه كفافات ويا مواد ديگر را از فيلتر بشوييد. مطمئن شويد كه پروانه پمپ تخليه در پشت فيلتر مسدود نشده باشد. سريوش فيلتر را سرجايش بگذاريد.
۵. پوشش فيلتر را سرجايش بگذاريد.

حفظ و نگه داري از ماشين لباسشويي



تميز كردن فيلتر توري لوله آب

بايستي فيلتر توري لوله آب را حداقل يكبار در سال تميز كنيد ويا هنگاميكه پيغام خطاي زير را بر روي نمايشگر مي بينيد:

4E

براي انجام اينكار:

۱. منبع آب ماشين لباسشويي را ببنديد.
۲. لوله را از پشت ماشين لباسشويي باز كنيد.
۳. با يك انبردست، به آرامي فيلتر توري را از ته لوله بيرون كشيده و آنرا زير آب بگيريد تا تميز شود. همچنين داخل و خارج اتصالي شياردار را تميز كنيد.



۴. فيلتر را سرجايش فشار دهيد.
۵. لوله را دوباره به ماشين لباسشويي پيچ كنيد.
۶. شير را باز كرده و مطمئن شويد كه اتصالي ها آب بندي شده باشند.

مشکلات و راه حل ها

ماشین لباسشویی شروع به کار نمی کند

- مطمئن شوید که درجه به طور محکم بسته شده است.
- مطمئن شوید که ماشین لباسشویی به پریز برق زده شده است.
- مطمئن شوید که شیر منبع آب باز شده باشد.
- مطمئن شوید که دکمه Start/Pause (شروع/مکث) را فشار دهید.

آب نیست ویا مقدار آب کافی نیست

- مطمئن شوید که شیر منبع آب باز شده باشد.
- مطمئن شوید که لوله منبع آب متجمد نشده باشد.
- مطمئن شوید که لوله ورودی آب خم نشده باشد.
- مطمئن شوید که فیلتر بر روی لوله ورودی آب مسدود نشده باشد.

بعد از اینکه برنامه شستشو کامل شد پودر لباسشویی در داخل کشویی پودر لباسشویی باقی می ماند.

- مطمئن شوید که ماشین لباسشویی با فشار آب کافی کار می کند.
- پودر لباسشویی را در بخش های داخلی کشویی پودر لباسشویی بگذارید (به دور از لبه های خارجی).

ماشین لباسشویی لرزش ویا زیادی سمرو صدا می کند

- مطمئن شوید که ماشین لباسشویی بر روی یک سطح هموار گذاشته شده باشد. اگر سطح هموار نیست، پایه های ماشین لباسشویی را تنظیم کنید تا هم تراز شود.
- مطمئن شوید که پیچ های حمل و نقل جدا شده باشند.
- مطمئن شوید که ماشین لباسشویی با شین دیگری تماس نداشته باشد.
- مطمئن شوید که توده لباس ها توازن نداشته باشند.

ماشین لباسشویی تخلیه ویا چرخش نمی کند

- مطمئن شوید که لوله تخلیه له ویا خم نشده باشد.
- مطمئن شوید که فیلتر توری لوله آب مسدود نشده باشد.

درجه باز نمی شود

۱. دوشاخه برق را از پریز برق بکشید.
۲. آب را از ماشین لباسشویی خارج کنید.
۳. پوشش فیلتر را با استفاده از یک سکه باز کنید.
۴. زبانه پلاستیکی نارنجی را پیدا کرده و برای باز کردن درجه آنرا به جلو بکشید.

شناسایی پیغام های خطا

خطای نمایش داده شده	راه حل
dE2	• درجه را ببندید.
4E	• مطمئن شوید که شیر منبع آب باز شده باشد. • فشار آب را کنترل کنید.
5E	• فیلتر کثافات را تمیز کنید. • مطمئن شوید که لوله تخلیه به طور صحیح نصب شده باشد.
UE	• توده لباس نامتوازن است؛ هرگونه لباس گره خورده را باز کنید. اگر تنها لایم است که یک قطعه لباس شسته شود. از قبیل یک رب شامپو ویا شلوار جین نتیجه چرخش نهایی ممکن است قابل قبول نبوده و یک پیغام خطای "UE" در پنجره نمایش نشان داده خواهد شد.
cE / 3E	• با مرکز تعمیر بعد از فروش تماس بگیرید.
HOT	• زمانی نشان داده می شود که درجه به خاطر دمای زیاد باز نمی شود.

قبل از تماس با مرکز تعمیر بعد از فروش:

۱. سعی کنید که مشکل را حل کنید (به "عیب یابی" در این صفحه رجوع شود).
۲. برنامه را دوباره شروع کنید تا ببینید که آیا خطا تکرار می شود.
۳. اگر درست کار نکردن ادامه پیدا کرد. با مرکز تعمیر بعد از فروش تماس گرفته و مشکل را تشریح کنید.

جدول برنامه

(*) گزینش کاربر

برنامه	حداکثر ظرفیت (کیلوگرم)		پودر لباسشویی و مواد افزودنی				درجه حرارت (C)	سرعت چرخش(حداکثر) دور در دقیقه		تأخیر در شروع	زمان چرخه (دقیقه)
	J147/J127	B147/B127	پیش شستشو	شستشو	نرم کننده	حداکثر		J147/B147	J127/B127		
نخی	۷/۰	۶/۰	*	بله	*	۹۵	۱۴۰۰	۱۲۰۰	*	۸۹	
رنگ شده	۷/۰	۶/۰	*	بله	*	۶۰	۱۴۰۰	۱۲۰۰	*	۹۷	
مصنوعي	۳/۰	۳/۰	*	بله	*	۶۰	۱۲۰۰	۱۲۰۰	*	۶۹	
پارچه ظریف	۲/۵	۲/۵	-	بله	*	۴۰	۸۰۰	۸۰۰	*	۵۲	
شستشو با دست برای پشمی	۲/۰	۲/۰	-	بله	*	۴۰	۸۰۰	۸۰۰	*	۳۹	
جین	۲/۰	۲/۰	*	بله	*	۴۰	۸۰۰	۸۰۰	*	۵۹	
سریع	۳/۰	۳/۰	-	بله	*	۶۰	۱۴۰۰	۱۲۰۰	*	۲۷	

نوع شستشو	برنامه
الیاف نخی. ملافه، رومی، زیرپوش، حوله، پیراهن و غیره که به طور متوسط ویا کم کثیف شده اند.	نخی
الیاف نخی. ملافه، رومی، زیرپوش، حوله، پیراهن و غیره که به طور متوسط ویا کم کثیف شده اند.	رنگ شده
بلوز پیراهن و غیره که به طور متوسط ویا کم کثیف شده اند. از جنس پلی استر (دیولین، تریورا)، پلی آمید (پرلون، نایلون) و ترکیبات مشابه دیگر.	مصنوعي
پرده، لباس، دامن، پیراهن و بلوزهای ظریف	پارچه ظریف
تنها لباس های پشمی قابل شستشو با ماشین با برچسب پشم خالص نو.	شستشو با دست برای پشمی
بلوز پیراهن، پارچه حوله های رنگ شده تیره، اقلام کتانی رنگ شده، شلوار جین و غیره که کمی کثیف شده اند	سریع

۱. اطلاعات مدت برنامه، خت شرابطی اندازه گیری شده که در Standard IEC 456 مشخص شده است.

۲. مقدار مصرف در خانه های مختلف ممکن است از مقادیری که در این جدول داده شده متفاوت باشد که به خاطر تنوع در فشار و دمای منبع آب، مقدار لباس ها و نوع لباسشویی است.

جدول برنامه

(* گزینش کاربر)

برنامه	حداکثر ظرفیت (کیلوگرم)		پودر لباسشویی و مواد افزودنی			درجه حرارت (C)	سرعت چرخش (حداکثر) دور در دقیقه		تأخیر در شروع	زمان چرخه (دقیقه)
	J147/J127	B147/B127	پیش شستشو	شستشو	نرم کننده		J147/B147	J127/B127		
خشک کردن	۳/۵	۳/۰	-	-	-	-	-	-	*	۱۲۰
بسیار کثیف	۷/۰	۶/۰	*	بله	*	۶۰	۱۶۰۰	۱۲۰۰	*	۱۰۸
توده لباس مخلوط	۲/۵	۲/۵	-	بله	*	۶۰	۸۰۰	۸۰۰	*	۷۵
شستشوی آرام	۳/۰	۳/۰	-	بله	*	۴۰	-	-	*	۹۵

نوع شستشو	برنامه
الیاف نخی، ملافه، رومیزی، زیرپوش، حوله، پیراهن و غیره که لکه دار و یا بسیار کثیف شده اند.	بسیار کثیف
مخلوطی از الیاف نخی کمی کثیف و پارچه های مصنوعی.	توده لباس مخلوط
میزان بسیار پایین سروصدا در حین کل چرخه و خاتمه نگه داشتن آبکشی، نخی، ملافه، رومیزی، زیرپوش، حوله، پیراهن.	شستشوی آرام

جدول مراقبت از پارچه

می توان در حداکثر ۱۰۰ درجه سانتی گراد اتو کرد		مواد مقاوم	
اتو نشود		پارچه ظریف	
می توان با استفاده از هر محلولی خشکشویی کرد		می توان در ۹۵ درجه سانتی گراد شست	
فقط با پرکلورید، سوخت فندک، الکل خالص ویا R۱۱۳ خشکشویی نشود		می توان در ۶۰ درجه سانتی گراد شست	
فقط با سوخت هواپیما، الکل خالص ویا R۱۱۳ خشکشویی نشود		می توان در ۴۰ درجه سانتی گراد شست	
خشکشویی نشود		می توان در ۳۰ درجه سانتی گراد شست	
به طور مسطح خشک شود		می توان با دست شست	
برای خشک کردن می توان آویزان کرد		فقط خشکشویی	
بر روی رخت آویز خشک شود		می توان در آب سرد رنگبری کرد	
ماشین خشک کن با حرارت عادی		رنگبری نشود	
ماشین خشک کن با حرارت کم		می توان در حداکثر ۴۰۰ درجه سانتی گراد اتو کرد	
از خشک کن استفاده نشود		می توان در حداکثر ۱۵۰ درجه سانتی گراد اتو کرد	

اخطارهای برقی

- برای کاهش خطر آتشسوزی، شوک برقی و صدمات دیگر، این احتیاط های ایمنی را به خاطر داشته باشید:
- از این دستگاه تنها با نوع برقی که در برچسب علامت گذاری شده مشخص شده استفاده کنید. اگر از نوع برقی که در خانه شما عرضه شده مطمئن نیستید، با فروشنده دستگاه ویا شرکت برق محلی خود تماس بگیرید.
- تنها از یک پریز زمینی ویا قطبی شده استفاده کنید. این دستگاه برای ایمنی شما مجهز به یک دوشاخه خط جریان متناوت قطبی شده می باشد که یک زبانه آن پهن تر از زبانه دیگر است. این دوشاخه تنها به یک صورت در پریز قرار خواهد کرد. اگر نمی توانید دوشاخه را به طور کامل وارد پریز کنید، دوشاخه را برگردانید. اگر دوشاخه در پریز وارد نمی شود، با تکنسین برق خود تماس بگیرید تا پریز را تعویض کند.
- از سیم برق محافظت کنید. سیم جریان برق بایستی طوری قرار بگیرد که احتمال راه رفتن بر روی آن ویا سوراخ شدن توسط اقلامی که بر روی آن گذاشته می شوند وجود نداشته باشد. به سیم ها در محل دوشاخه ها، پریزهای راحتی و نقطه ای که از دستگاه خارج می شوند توجه مخصوص مبذول کنید.
- پریزها و سیم های رابط را زبانی پر نکنید. زبانی پر کردن می تواند موجب آتشسوزی ویا شوک برقی شود.

محافظت از زیست محیط

- این دستگاه با استفاده از مواد بازیابی شده تولید شده است. اگر تصمیم گرفتید که این دستگاه را به دور بیندازید، لطفاً مقررات محلی دفع زباله را مراعات کنید. سیم برق را ببرید تا نتوان دستگاه را به منبع برق وصل کرد. دریچه را جدا کنید تا حیوانات و کودکان خردسال نتوانند در داخل دستگاه حبس نشوند.
- از مقدار پودر لباسشویی که در دستورالعمل های سازنده پودر لباسشویی توصیه شده جاوز نکنید.
- از محصولات پاک کردن لکه و مواد رنگبر تنها زمانی قبل از چرخه شستشو استفاده کنید که کاملاً لازم باشد.
- به ظرفیت کامل بشویید تا در مصرف آب و برق صرفه جویی نشود (مقدار دقیق بستگی به برنامه دارد که استفاده می شود).

اعلامیه سازگاری

این اسباب خانگی با استانداردهای ایمنی اروپایی EN Standard 60335 و EC directive 93/68 سازگار است.

مشخصات

ماشین لباسشویی با دریچه جلو				نوع	
B147/B127		J147/J127		ابعاد	
عرض ۵۹۸ در عمق ۵۵۰ در بلندی ۸۴۴ میلی‌متر		عرض ۵۹۸ در عمق ۶۰۰ در بلندی ۸۴۴ میلی‌متر			
۵۰ تا ۸۰۰ کیلوپاسکال				فشار آب	
۵۴ لیتر		۶۰ لیتر		مقدار آب	
B147/B127		J147/J127		وزن خالص	
۷۵ کیلوگرم		۷۸ کیلوگرم			
۶/۰ کیلوگرم (لباس خشک)		۷/۰ کیلوگرم (لباس خشک)		شستشو	ظرفیت شستشو و خشک کردن
۳/۰ کیلوگرم (لباس خشک)		۳/۵ کیلوگرم (لباس خشک)		خشک کردن	
B147/B127		J147/J127		مدل	
۱۵۰ وات	۲۳۰ وات	۱۵۰ وات	۲۳۰ وات	شستشو	
۲۰۰۰ وات	۲۲۰ ولت	۲۰۰۰ وات	۲۲۰ ولت	شستشو و گرم کردن	
۲۴۰۰ وات	۲۴۰ ولت	۲۴۰۰ وات	۲۴۰ ولت	خشک کردن	
۲۰۰۰ وات	۲۲۰ ولت	۲۰۰۰ وات	۲۲۰ ولت		
۲۴۰۰ وات	۲۴۰ ولت	۲۴۰۰ وات	۲۴۰ ولت	پمپ	
۳۴ وات					
B147/B127		J147/J127		مدل	
۲/۵ کیلوگرم		۲/۵ کیلوگرم		کافت	
۱/۰ کیلوگرم		۱/۰ کیلوگرم		پلاستیک	
J127/B127		J147/B147		مدل	
۱۴۰۰		۱۴۰۰		دور در دقیقه	



با SAMSUNG WORLD WIDE تماس بگیرید
اگر سوال و یا نظری در مورد محصولات Samsung دارید، لطفاً با مرکز مراقبت از مشتریان
SAMSUNG تماس بگیرید.